


20/06/2001 GB G01 ↑
0271 05 **5018** 62
PAGE 1

31/06/2001
CONSOLE HARNESS



04/95 M5018620

M5018620


MULTIPLEXING ASSEMBLY
TO O 07846

		CONSOLE HARNESS	
1	6527 K5 01	TO O 06747	
	6521 ER 01	FROM O 06748 TO O 07111	
	6521 YE 01	REPARE 9629281880 REF 9628827680 FROM O 07112	
5	6527 K4 01	TO O 07111	
	6521 PQ 01	REPARE 9628006880 FROM O 07112 TO O 07482	
	6521 YG 01	REPARE 9630832180 FROM O 07483	

20/06/2001 GB F15 ↓
J271 05 5018 03C
PAGE 1

31/08/2001


FACIA PANEL CONSOLE HARNESS



M501803C

- FROM O 07483
- LEFT HAND DRIVE, WITHOUT MULTIPLEXING

1	6521 YH 01	FACIA HARNESS REPERE 9830576680 -NO COMPUTER TO O 07847
	6521 W5 01	REPERE 9834382280 -NO COMPUTER FROM O 07847
	6521 YJ 01	REPERE 9830578780 -COMPUTER TO O 07847
	6517 80 01	REPERE 98306598C -COMPUTER (RMP REF 9834382480 TO O 08028) FROM O 08029
5	6527 87 01	FULLER HARNESS REPERE 981*918780 -WITHOUT THEFT PROTECTION ALARM, LOCKING REMOTE CONTROL W/O FREQUENCY: SPEED CONTROL OR TURBO DIESEL DK5ATE
	6521 NX 01	REPERE 9827072080 - 9827072180 -WITHOUT THEFT PROTECTION ALARM, LOCKING REMOTE CONTROL W/O FREQUENCY, WITHOUT SPEED CONTROL EXCEPT TURBO DIESEL DK5ATE OR LOCKING REMOTE CONTROL WITH FREQUENCY
8	6514 XJ 01	AIR-BAG HARNESS REPERE 9838208180
8	6517 S1 01	ALARM LOOM REPERE 9835068080 -(J)
10	6544 JT 01	SIGNAL HARNESS REPERE 9823368780 -SPEED CHECK
15	6542 94 01	EARTH CONTACT A=5
	RP 6541 J7 01	
20	95 604 802 02	PROTECTOR LONG 300 P001 PVC
22	96 078 959 01	
23	6555 TG 01	SECTION

FACIA PANEL CONSOLE HARNESS**- LEFT HAND DRIVE, WITHOUT MULTIPLEXING
- TO O 06747**


M501801B

1	6527 81 01	FACIA HARNESS REPERE 9815817180 -SX TO O 06585
	6527 82 01	REPERE 9815817380 -LEVEL VSX, NO COMPUTER TO O 06585
	6527 83 01	REPERE 9815817480 -TO O 06585 - LEVEL VSX, COMPUTER OR EXCLUSIVE, PETROL OR EXCLUSIVE, TURBO DIESEL DK5ATE
	6527 84 01	REPERE 9815817580 -TO O 06585 -EXCLUSIVE: TURBO DIESEL XUD11ATE OR TURBO DIESEL XUD11BTE
	6527 R7 01	REPERE 9823813580 -SX FROM O 06566
	6527 R8 01	REPERE 9823813880 -LEVEL VSX, NO COMPUTER FROM O 06566
	6527 S1 01	REPERE 9823813880 FROM O 06566 - LEVEL VSX, COMPUTER OR EXCLUSIVE, PETROL OR EXCLUSIVE, TURBO DIESEL DK5ATE
	6527 R9 01	REPERE 9823813780 -FROM O 06566 -EXCLUSIVE: TURBO DIESEL XUD11ATE OR TURBO DIESEL XUD11BTE
5	6527 87 01	FULLER HARNESS REPERE 9815818780 - WITHOUT THEFT PROTECTION ALARM
	6527 88 01	FACIA HARNESS REPERE 9815818180 REF 9815817980 - ANTI-THEFT ALARM
10	6544 JT 01	SIGNAL HARNESS REPERE 9823368780

20/08/2001 GB E11 ↑
0271 05 **5018** 01B
PAGE 2

31/08/2001

FACIA PANEL CONSOLL HARNESS




15	6542 94	01	EARTH CONTACT A=5
	RP 6541 J7	01	
20	95 604 802	02	PROTECTOR
22	96 079 959	01	LONG 300
23	6555 TG	01	SECTION
24	1982 44	02	BOX BRACKET
25	1537 47	01	SHIM 50X50 EP 15
			CONNECTR BRACKT
26	6555 TF	01	
27	6555 FV	01	
28	6555 1E	01	FLANGE
			HOG RING
30	061 501	01	L 51X27 H34
31	6995 T3	01	DIAM 8,2-L = 50,5
32	6995 05	09	
33	6992 H3	01	DIAM 11-18
34	6986 79	01	1T 6,2
35	6992 16	01	DIAM 16 L32X32,5
36	6986 81	01	DIAM 17
37	6986 89	01	
			STRAP
40	6980 28	12	LONG 275 LARG 5
41	6981 G8	01	LONG 200 LARG 5

20/06/2001 GB E12 ↑
0271 05 5018 02B
PAGE 1

31/08/2001

FACIA PANEL CONSOLE HARNESS



- FROM O 06748 TO O 07083
- LEFT HAND DRIVE, WITHOUT MULTIPLEXING


1	6527 X7	01	FACIA HARNESS REPERE 9623837280 -BX, NO COMPUTER TO O 06936
	6527 X8	01	REPERE 9623837380 -NO COMPUTER EXCEPT BX TO O 06936
	6527 X9	01	REPERE 9623837580 -COMPUTER TO O 06936
	6521 GP	01	REPERE 9625236580 -BX, NO COMPUTER FROM O 06937
	6521 GQ	01	REPERE 9625236680 -NO COMPUTER EXCEPT BX FROM O 06937
	6521 GR	01	REPERE 9625236780 -COMPUTER FROM O 06937
5	6527 87	01	FULLER HARNESS REPERE 9615816780 - WITHOUT THEFT PROTECTION ALARM
	6527 86	01	FACIA HARNESS REPERE 9615816180 -TO O 06936 - ANTI-THEFT ALARM REF 9615817080 REF 9615817980
	6521 GW	01	REPERE 9626715380 -FROM O 06937 - ANTI-THEFT ALARM REF 9626715580
10	6544 JT	01	SIGNAL HARNESS REPERE 9623368780
15	6542 94	01	EARTH CONTACT A=5
	RP 6541 JT	01	
20	95 604 802	02	PROTECTOR LONG 300
22	96.079 959	01	
23	6555 TG	01	SECTION
24	1982 44	02	BOX BRACKET

M501802B

20/03/2001 GB E13 ↑
0271 05 **5018** 02B
PAGE 2


31/03/2001

FACIA PANEL CONSOLE HARNESS



M501802B

25	1537 47	01	SHIM 50X50 EP 15
26	6555 TF	01	CONNECTR BRACKT
27	6555 FV	01	
28	6555 TE	01	FLANGE
			HOG RING
30	96 061 501	01	L 51X27 H34
31	6995 T3	01	DIAM 6.2-L=50.5
32	6995 05	09	
33	6992 H3	01	DIAM 11-18
34	6996 79	01	1T 6.2
35	6992 16	01	DIAM 16 L32X32.5
36	6996 81	01	DIAM 17
37	6996 89	01	
			STRAP
40	6980 28	12	LONG 275 LARG 5
41	6981 G9	01	LONG 200 LARG 5




- FROM O 07084 TO O 07482
- LEFT HAND DRIVE, WITHOUT MULTIPLEXING

1	6521 NN 01	FACIA HARNESS REPERE 9827071080 -8X, NO COMPUTER TO O 07317
	6521 NP 01	REPERE 9827071180 -NO COMPUTER EXCEPT 8X TO O 07317
	6521 NQ 01	REPERE 9827071280 -COMPUTER TO O 07317
	6521 WW 01	REPERE 9828752380 -8X, NO COMPUTER FROM O 07318
	6521 WX 01	REPERE 9828752480 -NC COMPUTER EXCEPT 8X FROM O 07318
	6521 WY 01	REPERE 9828752580 -COMPUTER FROM O 07318
5	6527 BT 01	FULLER HARNESS REPERE 9615818780 -WITHOUT THEFT PROTECTION ALARM, LOCKING REMOTE CONTROL W/O FREQUENCY: SPEED CONTROL OR TURBO DIESEL DK5ATE
	6521 NX 01	REPERE 9827072080 - 9827072180 -WITHOUT THEFT PROTECTION ALARM: LOCKING REMOTE CONTROL W/O FREQUENCY, WITHOUT SPEED CONTROL EXCEPT TURBO DIESEL DK5ATE OR LOCKING REMOTE CONTROL WITH FREQUENCY
	6521 NV 01	FACIA HARNESS REPERE 9827071880 - 9827071880 -ANTI-THEFT ALARM
10	6544 JT 01	SIGNAL HARNESS REPERE 9823388780
15	6542 R4 RP 6541 J7 01	EARTH CONTACT A=5
20	95 604 892 02	PROTECTOR LONG 300
22	96 079 959 01	
23	6555 TG 01	SECTION

31/08/2001

FACIA PANEL, CONSOLE HARNESS

PAGE 2



M501803B

1982 44 02 BOX BLACKET

1537 47 01 SHIM 50X50 EP 15

CONNECTR BRACKET

6555 TF-01

6555 FV 01

8555 TE|01|FLANGE

HOG KING

88 061 501 01 L 51X2 34

6995 T3|01|DIAM 8,2--L=50,5

6995 05/09

6002 HS 01/DIAM 11-18

8986 79 01 1T 6.2

6992 16 01 DIAM 16 L32X32,5

6986 61 01 DIAM 17

6986 89 01

STRAP


6980 28 12 LONG 275 LARG 5

6981 09 01 LONG 200 LARG 5

20/08/2001 GB FC ↓
0271 05 5013 60D
PAGE 2

31/08/2001

CONSOLE HARNESS



03/01/01 M501860D

M501860D

15 6542 94

RP 6541 J7 01

20 86 063 320

22 6555 T/4

24 95 583 416

28 6542 94

30 6992 G8

31 6995 T3

33 26 141 629

35 6980 47

01 EARTH CONTACT A=5

02 PROTECTOR

01 CONNECTR BRACKT TOL EP 0 8

01 FIXING BRACKET

01 SHEATH DIAM 23X28 LONG 2000


HOG RING

02 1 T 13

01 DIAM 6,2-L=50,5

01 ADJUST COLLAR LONG 151,5 LARG 8

01 STRAP LONG 171 LARG 9



[03/97] MSD1690D

MS01360D


- ELECT CONTR RR WINDOW LIFTER + LOCK SYSTEM, WITHOUT MULTIPLEXING

CONSOLE HARNESS	
6533 J1	01 REPERE 9620467980 -MANUAL FRONT SEAT CONTROL, FRONT ARMREST MANUAL, NON HEATED SEAT EXCEPT (AUS) TO O 06936
6533 J2	01 REPERE 9615818530 -FRONT SEAT ELECTRIC CONTROL, FRONT ARMREST MANUAL, NON HEATED SEAT EXCEPT (AUS) TO O 06936
6533 J3	01 REPERE 9615819620 -TO O 06936 -EXCEPT (AUS): HEATED SEAT OR FRONT ARMREST ELECTRIC
6533 S2	01 REPERE 9622682580 -(AUS) TO O 06936
6533 S5	01 REPERE 9625237580 -MANUAL FRONT SEAT CONTROL, FRONT ARMREST MANUAL, NON HEATED SEAT EXCEPT (AUS) FROM O 06937 TO O 07328
6533 S6	01 REPERE 9625237680 -FRONT SEAT ELECTRIC CONTROL, FRONT ARMREST MANUAL, NON HEATED SEAT EXCEPT (AUS) FROM O 06937 TO O 07328
6533 S7	01 REPERE 9625237780 -FROM O 06937 TO O 07328 -EXCEPT (AUS): HEATED SEAT OR FRONT ARMREST ELECTRIC
6533 S8	01 REPERE 9625237880 -(AUS) FROM O 06937 TO O 07328
6533 W5	01 REPERE 9628753680 - 9628753780 - 9628753880 -EXCEPT (AUS) FROM O 07329
6533 X3	01 REPERE 96328753280 -(AUS) FROM O 07329 TO O 07647
6533 Y7	01 REPERE 9634540980 -(AUS) FROM O 07647

20/06/2001 GB F03 ↓
0271 05 **5018** 60A
PAGE 2

31/08/2001

CONSOLE HARNESS



03/87 MS01880A

MS01880A



35

6980 47 01 STRAP LONG 171 LARG 9

20/08/2001 GB F04 ↓
0271 05 **5018** 60A
PAGE 1

31/08/2001

CONSOLE HARNESS



[03/07] M501860A

M501860A


- WITHOUT MULTIPLEXING :
WITHOUT REAR GLASS LIFT OR MAN CTRL REAR WINDOW
LIFTER

1		CONSOLE HARNESS
6533 H8	01	REPERE 9615819280
		-MANUAL FRONT SEAT CONTROL. NON HEATED SEAT TO O 06828
6533 S2	01	REPERE 9822682580
		-TO O 06936
		REF 9622339380 - 9615819480
		- FRONT SEAT ELECTRIC CONTROL OR MANUAL FRONT SEAT CONTROL
6533 S3	01	REPERE 9625237180
		-MANUAL FRONT SEAT CONTROL. NON HEATED SEAT FROM O 06937 TO O 07328
6533 S9	01	REPERE 9625237380
		-FROM O 06937 TO O 07328
		- FRONT SEAT ELECTRIC CONTROL REF 9625237480 - 9625237280
		OR MANUAL FRONT SEAT CONTROL REF 9625237480 - 9625237280
6533 W4	01	REPERE 9628753180 - 9628753280 - 9628753380
		9628753480 - 9628753580
		FROM O 07328
6533 CK	01	REPERE 9637183180
		-DRIVERS FRT SEAT MANUAL CNTRL. NON HEATED SEAT
15 6542 94	01	EARTH CONTACT A=5
RP: 6541 J7	01	
20 96 063 320	02	PROTECTOR
22 6555 TA	01	CONNECTR BRACKT TOLE EP 0 8
24 95 596 946	01	FIXING BRACKET
28 6542 98	01	SM EATH DIAM 23X29 LONG 2000
		HOG RING
30 6942 G6	02	1 T 13
31 6995 T3	01	DIAM 6.2-L=50,5
33 26 141 629	01	ADJUST COLLAR LONG 151,5 LARG 8

20/06/2001 GB F05 ↓
0271 05 5018 34
PAGE 2

31/08/2001

FACIA PANEL CONSOLE HARNESS



96 061 501 01 HOG RINC
L 51X27 H34
6995 T3 01 DIAM 6.2--L=50.5
6995 G5 14
6J02 H3 02 DIAM 11-18
6986 T9 01 1T 6.2
6992 6 01 DIAM 18 L32X32.5
79 03 076 165 02 PING E2 ES L18X15
NFP
6992 A8 02 1.5-3-8.5
6992 A8 01 DIAM 6-12
6997 87 01 1T 37
STRAP
6981 G9 02 LONG 200 LARG 5
6980 21 08 LONG 275 LARG 5


M5018340

31/08/2001

0271 05 **5018** 34

PAGE

FACIA PANEL CONSOLE HARNESS



M5018340

- FROM O 07483
- RIGHT HAND DRIVE

FACIA HARNESS

5521-YK REPERE 983057C-80
-NO COMPUTER TO 0 07847

6521 W7 01 REPERE 8634362380
-NO COMPUTER FROM O 07847 TG Q 02210

6521 YL/01 REPLYE 9830578920
-COMPUTER TO O 07847

6521 W8 01 REPERE 9834382580
-COMPUTER FROM G 07847

FULLER HARNESS

5521 NX 01 REPURE 9827072080 - 9827072180
-WITHOUT THEFT PROTECTION ALARIM LOCKING
REMOTE CONTROL W/O FREQUENCY, WITHOUT SPEED
CONTROL EXCEPT TURBO DIESEL DKS/TE

REPERE 0615818A80
WITHOUT THEFT PROTECTION ALARM, LOCKING
REMOTE CONTROL W/O FREQUENCY:
SPEED CONTROL
OR TURBO DIESEL DK54TE

602 P-1 REPERE 9826243780 - 9826243880
-WITHOUT THEFT PROTECTION ALARM, LOCKING
REMOTE CONTROL WITH FREQUENCY

15	6542 94	01	EARTH CONTACT A=5
	RP 6541 .17	01	

20	95 604 802 02	PROTECTOR LONG 300 P001 PVC
----	---------------	--------------------------------

21	96 013 150	03	SENSOR BRACKET
			CONNECTR BRACKET

23	6555 FV	01
----	---------	----

24 96 070 452 01

26 6555 TG 01 SECTION

27	6992 52 01	HOG RING
----	------------	----------

28	6992 G2.02	RETAINING CLIP DIAM 4.2
----	------------	-------------------------


20/06/2001 G3 F07 ↓

31/08/2001

0271 05 5018 33

FACIA PANEL CONSOLE HARNESS

PAGE 2



W0018330

96 070 452 01

CONNECTR BRACKET

6535 TG 01

SECTION

6992 52 01

HOG RING

6992 G2 02

RETAINING CLIP DIAM 4.2

HOG RING

96 061 501 1

L 5 X 27 H 34

6995 T3 01

DIAM 6.2-L=50.5

6995 G5 14

6992 H3 02

DIAM 11-18

6986 79 U1

1T 6.2

6992 16 01

DIAM 16 L32X32.5

79 03 076 165

PINC E2 E3 L18X15

NFP

6992 A3 02

1.5-4-8.5

6992 A6 01

DIAM 6-12

6997 87 U1

1T 37

STRAP

6981 G9 02

LONG 200 LARG 5


6980 28 08

LONG 275 LARG 5

20/08/2001 GB F08 ↓
0271 05 **5018** 33
PAGE 1

31/08/2001

FACIA PANEL CONSOLE HARNESS



M5018330

- FROM O 07084 TO O 07482
- RIGHT HAND DRIVE


	FACIA HARNESS
1	6521 NR 01 REPERE 9827071380 -SX NO COMPUTER TO O 07317
	6521 NS 01 REPERE 9827071480 -NO COMPUTER EXCEPT SX TO O 07317
	6521 NT 01 REPERE 9827071500 -COMPUTER TO O 07317
	6521 WZ 01 REPERE 9828752880 -SX, NO COMPUTER FROM O 07318
	6521 XA 01 REPERE 9828752780 -NO COMPUTER EXCEPT SX FROM O 07318
	6521 XC 01 REPERE 9828752880 -COMPUTER FROM O 07318
	FULLER HARNESS
5	6521 NX 01 REPERE 9827072080 - 9827072180 -WITHOUT THEFT PROTECTION ALARM, LOCKING REMOTE CONTROL W/O FREQUENCY, WITHOUT SPEED CONTROL EXCEPT TURBO DIESEL DK5ATE
	6527 94 01 REPERE 9815818880 -WITHOUT THEFT PROTECTION ALARM, LOCKING REMOTE CONTROL W/O FREQUENCY: SPEED CONTROL OR TURBO DIESEL DK5ATE
	6521 PP 01 REPERE 9828243780 - 9828243880 -WITHOUT THEFT PROTECTION ALARM, LOCKING REMOTE CONTROL WITH FREQUENCY
	6521 NW 01 FACIA HARNESS REPERE 9827071780 - 9827071880 -ANTI-THEFT ALARM
15	6542 94 01 EARTH CONTACT A=5
	RP 6541 J7 01
20	95 804 802 02 PROTECTOR LONG 300
21	96 013 150 03 SENSOR BRACKET
	CONNECTR BRACKET
23	6555 FV 01

20/08/2001 GB F09 ↓

31/08/2001

0271 05 **5018** 32**FACIA PANEL CONSOLE HARNESS**

PAGE 2

28
30
31
32
33
34
35
36
37
38
39
40
41

6992 G2 02 RETAINING CLIP DIAM 4.2

HOG RING

96 081 501 01 L 51X27 H34

6995 T3 01 DIAM 6.2-L-50.5

6995 02 14

6992 H3 02 DIAM 11-18

6986 T9 01 1T 6.2

6992 16 01 DIAM 16 L32X33.5

79 03 076 165 02 PINC E2 E3 L18X15
NFP

6992 A8 02 1.5-3-6.5

6992 A6 01 DIAM 8-12

6997 37 01 1T 37

STRAP

6981 G9 02 LONG 200 LARG 5

6980 28 08 LONG 275 LARG 5

M5018320

20/06/2001 GB F10 ↓
 0271 05 5018 32
 PAGE 1

31/08/2001

FACIA PANEL CONSOLE HARNESS





FIGURE M5018320

M5018320

- FROM O 06748 TO O 07083
 RIGHT HAND DRIVE

1	6527 Y1 01	FACIA HARNESS REPERE 0623937840 -SX. NO COMPUTER TO O 06936
	6527 Y2 01	REPERE 0623937780 -NO COMPUTER EXCEPT SX TO O 06936
	6527 Y3 01	REPERE 0623937980 -COMPUTER TO O 06936
	6521 G5 01	REPERE 0625236880 -SX. NO COMPUTER FROM O 06937
	6521 GT 01	REPERE 0625236980 -NO COMPUTER EXCEPT SX FROM O 06937
	6521 GV 01	REPERE 0625237080 -COMPUTER FROM O 06937
5	6527 94 01	FULLER HARNESS REPERE 0615818880 - WITHOUT THEFT PROTECTION ALARM
	6527 93 01	FACIA HARNESS REPERE 0615818280 -TO O 06936 REF 0615818080 - ANTI-THEFT ALARM
	6521 GX 01	REPERE 0626715480 -FROM O 06937 REF 0626715880 - ANTI-THEFT ALARM
15	6542 94 01	EARTH CONTACT A=5
	RP 6541 J7 01	
20	95 604 802 02	PROTECTOR LONG 300
21	96 012 350 03	SENSOR BRACKET
		CONNECTR BRACKT
23	6555 FV 01	
24	96.070 452 01	
26	6555 TG 01	SECTION
27	6992 52 01	HOG RING




CONNECTR BRACKT

23	6555 FV	01	
24	96 070 452	01	
25	6555 TG	01	SECTION
26	6992 52	01	HOG RING
27	6992 G2	02	RETAINING CLIP DIAM 4,2
28			
29			
30	96 061 501	01	HOG RING
31			L 51/27 H34
32	6995 T3	01	DIAM 6,2-L = 50,5
33	6995 05	14	
34	6992 H3	02	DIAM 11-18
35	6906 79	01	1T 6,2
36	6992 16	01	DIAM 16 L32X32,5
37	73 03 076 165	02	PINC E2 E3 L18X15
38	NFP		
39	6992 A8	02	1,5-3-6,5
40	6992 A6	01	DIAM 6-12
41	6997 87	01	1T 37
			STRAP
	6581 C9	02	LONG 200 LARG 5
	6980 28	03	LONG 275 LARG 5

20/06/2001 GB F12 ↓

31/06/2001

0271 05 **5018** 30
PAGE 1**FACIA PANEL CONSOLE HARNESS****- RIGHT HAND DRIVE
- TO O 06747**


1		FACIA HARNESS
	6527 88 01	REPERE 9620397880 -SX TO O 06565
	6527 89 01	REPERE 9615817680 -LEVEL VSX, NO COMPUTER TO O 06565
	6527 90 01	REPERE 9615817780 -TO O 06565 - LEVEL VSX, COMPUTER OR EXCLUSIVE, PETROL OR EXCLUSIVE, TURBO DIESEL DK5ATE
	6527 91 01	REPERE 9615817880 -EXCLUSIVE, TURBO DIESEL XUD11ATE TO O 06565
	6527 92 01	REPERE 9623813980 -SX FROM O 06566
	6527 93 01	REPERE 9623814080 -LEVEL VSX, NO COMPUTER FROM O 06566
	6527 95 01	REPERE 9623814280 -FROM O 06566 - LEVEL VSX, COMPUTER OR EXCLUSIVE, PETROL OR EXCLUSIVE, TURBO DIESEL DK5ATE
	6527 94 01	REPERE 9623814180 -EXCLUSIVE, TURBO DIESEL XUD11ATE FROM O 06566
5	6527 94 01	FULLER HARNESS REPERE 9615818880 - WITHOUT THEFT PROTECTION ALARM
	6527 93 01	FACIA HARNESS REPERE 9615818280 REF 9615816080 -ANTI-THEFT ALARM: SPEED CONTROL OR TURBO DIESEL DK5ATE
15	6542 94	01 EARTH CONTACT A=5
	RP 6541 J7	01
20	95 604 802	02 PROTECTOR LONG 300
21	96 013 150	03 SENSOR BRACKET

M5018300

20/08/2001 GP F-3

31/08/2001

FACIA PANEL CONSOLE HARNESS

0271 05 5018 18
PAGE 1

01/1999 M5018180

M5018180

- MULTIPLEXING ASSEMBLY
- TO O 07846


1	6527 K7	01	FACIA HARNESS REPARE 9622870180 TO O 06747
	6521 AA	01	REPARE 9624180080 FROM O 06748 TO O 06932
	6521 EQ	01	REPARE 9628274480 FROM O 06933 TO O 07111
	6521 PR	01	REPARE 9628827980 FROM O 07112 TO O 07482
	6521 YF	01	REPARE 9629281680 FROM O 07483
5	6527 K6	01	REPARE 9622860080

1982	44	02	BOX BRACKET
1537	47	01	SHIM 50X50 EP 15
			CONNECTR BRACKET
6555	TF	01	
6555	FV	01	
6555	TE	01	FLANGE
			HOG RING
86 061	5C1	01	L 51X27 H34
6995	T3	01	DIAM 6.2-L = 50.5
6995	05	09	
6992	H3	01	DIAM 11-18
6986	79	01	1T 6.2
6992	16	01	DIAM 16 L32X32.5
6986	81	01	DIAM 17
6986	39	01	
			STRAP
6980	28	12	LONG 275 LARG 5
6981	G9	01	LONG 200 LARG 5

20/06/2001 GB G02 ↑
0271 05 5019 01
PAGE 1

31/08/2001

HEATER HARNESS AND AIRCONDITIONING



03/91

M5019010

M5019010

6445 Z7 01 HEATER WIRING
VALEO (THERMIQ)
-WITHOUT AIR CONDITIONING:
LEFT HAND DRIVE

6445 Q9 01 HARNESS A/CONDI
-WITHOUT AIR CONDITIONING, WITH SIMPLE
REGULATION AIRCON/TEMP, LEFT HAND DRIVE

6445 R1 01 -SINGLE AIR CONDITIONING, WITH SIMPLE REGULATION
AIRCON/TEMP, LEFT HAND DRIVE

6445 R3 01 -AUTOMATIC AIR CONDITIONING, LEFT HAND DRIVE

6445 Z7 01 HEATER WIRING
VALEO (THERMIQ)
-WITHOUT AIR CONDITIONING

6445 R0 01 HARNESS A/CONDI
-WITHOUT AIR CONDITIONING, WITH SIMPLE
REGULATION AIRCON/TEMP, RIGHT HAND DRIVE

6445 R2 01 -SINGLE AIR CONDITIONING, WITH SIMPLE REGULATION
AIRCON/TEMP, RIGHT HAND DRIVE

6445 R4 01 -AUTOMATIC AIR CONDITIONING, RIGHT HAND DRIVE